ECE 201 Foundations of Electric Circuits Laboratory Assignment 5 Worksheet Dr. Scoles Updated by Keith Zuckerman, Fall 2022

| Name | Date | |
|------|------|--|
|------|------|--|




Fig. 1. Circuit to be evaluated. Vsrc = 15 V, Isrc = 12.5 mA, R1 = 4.7 k Ω , R2 = 2.2k Ω , R3 = 3.3 k Ω .

Exercise 1. Theory

- Use the mesh method to find the mesh currents I1, I2, and I3. Do your work on this worksheet.
- Find V1, the voltage across the current source
- Find the currents through each resistor, I(R1), I(R2), and I(R3)
- Enter the resistor currents in Table 1

Exercise 2. Simulation

- Capture the Fig. 1 schematic in Multisim. Add and complete the course title block.
 - Save as LastName_FirstName_Assign5.ms14
- Measure the voltage across Isrc and display on the schematic.
- Measure the current through each resistor and display each value on the schematic.
 - o I(R1) will represent the current entering the + terminal of resistor 1
 - o Remember that the mesh currents do not necessarily equal the "real" currents
- Simulate the circuit and record the voltage and current measurements in Table 1.
- Prepare a PDF version of your completed schematic (including all of the above measurements) for upload, LastName_FirstName_Assign5.pdf

Exercise 3. Measurement

- Build the circuit from Fig. 1 on your breadboard.
- Using one set of banana-to-alligator leads, connect the red test lead to the positive terminal and the black test lead to the negative terminal of Channel 2 (Green). This will be the current source.
- Using the second set of banana-to-alligator leads, connect the red test lead to the positive terminal and the black test lead to the negative terminal of Channel 3 (Blue). This will be the voltage source.
 - Consider the polarity of the voltage source when connecting the alligator clips to your circuit.
- Select the Channel 2 output selection key and adjust the current to 12.5 mA. Press Enter to complete the entry.
 - Note: By limiting the current to 12.5 mA, this channel will operate as a current source in constant current (CC) mode.
- Select the Channel 3 output selection key and adjust the voltage to 15 V. Press Enter to complete the entry.
 - As a safety precaution, set the current for Channel 3 to 100 mA. This will have no impact on the performance of the circuit but will limit the current in the case of a short.
- Turn on the outputs for Channel 2 and Channel 3.
- Using the third set of banana-to-alligator leads, use the DMM to measure V1. Record the result in Table 1.
- Turn off the outputs and reconfigure the DMM test leads to measure the current through R1. Turn the outputs back on and record the results in Table 1.
- Repeat the previous step for R2 and R3.

Table 1. Comparison of Analysis Results

| | Theory | Simulation | Measurements |
|------------|--------|------------|--------------|
| V1 (V) | | | |
| I(R1) (mA) | | | |
| I(R2) (mA) | | | |
| I(R3) (mA) | | | |

At the end of the lab session:

- 1. Upload your schematic in PDF form to the assignment's Bb Learn page
- 2. Turn in a completed worksheet